



- | | | |
|------|---|------------------|
| 1. | Refrigerator door assembly | K-12831000001022 |
| 1.1 | Door gasket assembly of refrigerator | K-12131000009892 |
| 5. | Upper hinge assembly | K-12231000006851 |
| 6. | Refrigerator rollbond evaporator | K-15733000000006 |
| 8. | Steel wire shelf of refrigerator | K-12931000000162 |
| 9. | Fixed base | K-12231000006457 |
| 10. | Beer barrel base pad | K-12231000007180 |
| 11. | Lower hinge adjust feet assembly | K-12231000006867 |
| 12. | Universal wheel | K-12931000000687 |
| 14. | Drain tray | K-12131000000704 |
| 16. | Guard bar of top cover | K-12131000004346 |
| 17. | Cabinet assembly | K-12931000000251 |
| 19. | Hole cap | K-12831000004364 |
| 20. | Constant temperature reset type
temperature controller | K-17431000000186 |
| 21. | Temperature-control box | K-12131000004772 |
| 22. | Button | K-12131000003600 |
| 27. | Power cord | K-17431000000303 |
| 28. | Drain tray | K-12131000004317 |
| 29. | Fixed Speed Reciprocating
Compressor | K-11101010010315 |
| 29.1 | Starter | K-12031000001584 |
| 29.2 | Protector | K-12031000001301 |
| 29.3 | Electric appliance shield | K-12031000001171 |
| 30. | Compressor back cover | K-12931000000648 |
| 31. | Compressor mounting panel | K-12231000005917 |
| 104. | Wrench | K-12931000000658 |
| 106. | Spout plug | K-12631000000188 |