



1.	Refrigerator door assembly	K-12831000001310
1.1	Door gasket assembly of refrigerator	K-12131000010476
1.2	Stopper	K-12231000007247
5.	Upper hinge assembly	K-12231000007048
6.	Refrigerator rollbond evaporator	K-15733000000009
7.	Locking buckle	K-12131000000877
8.	Steel wire shelf of refrigerator	K-12931000000074
9.	Fixed base	K-12231000006457
10.	Beer barrel base pad	K-12231000007178
11.	Lower hinge adjust feet assembly	K-12231000006867
12.	Universal wheel	K-12931000000687
13.	Levelling feet	K-12131000000999
14.	Drain tray assembly	K-12131000004291
15.	Top cover assembly	K-12131000033581
15.1	Locking buckle	K-12131000000876
16.	Guard bar of top cover	K-12931000000189
17.	Cabinet assembly	K-12831000005378
19.	Hole cap	K-12631000000187
20.	Constant temperature reset type temperature controller	K-17431000000189
21.	Temperature-control box assembly	K-12131000000952
22.	Screen printing knob	K-12131000003474
27.	Power cord	K-17431000000319
28.	Drain tray	K-12131000004317
29.	Fixed Speed Reciprocating Compressor	K-11101010012275
29.1	Starter	K-12031000001561
29.2	Protector	K-12031000001316
29.3	Electric appliance shield	K-12031000001171
30.	Compressor back cover	K-12931000000647
31.	Compressor mounting panel assembly	K-12231000005846
32.	Universal wheel	K-12931000000685
34.	Upper hinge assembly	K-12231000007166
106.	Spout plug	K-12631000000188
107.	Guard Rail Insert	K-12631000000190