



1.	Refrigerator door assembly	K-12831000A06028
1.1	Door gasket assembly of refrigerator	K-12131000010476
1.2	Stopper	K-12231000007247
2.	Display control panel	K-17131000000026
3.	Display control panel mounting box	K-12131000000445
4.	Sensor cover	K-12131000001064
5.	Upper hinge assembly	K-12231000007048
6.	Refrigerator rollbond evaporator	K-15733000000009
7.	Locking buckle	K-12131000000877
8.	Steel wire shelf of refrigerator	K-12931000000074
9.	Fixed base	K-12231000006457
10.	Beer barrel base pad	K-12231000007178
11.	Lower hinge adjust feet assembly	K-12231000006867
12.	Universal wheel (non-locking casters)	K-12931000000687
13.	Levelling feet	K-12131000000999
14.	Drain tray assembly	K-12131000004291
15.	Top cover assembly	K-12131000033582
15.1	Locking buckle	K-12131000000876
16.	Guard bar of top cover	K-12931000000189
17.	Cabinet assembly	K-12831000004750
19.	Hole cap	K-12631000000187
23.	Fan motor	K-11002015001682
24.	Plastic cover	K-12131000001191
25.	Main control board	K-17131000000140
26.	Mounting box assembly	K-12131000001673
27.	Power cord	K-17431000000281
28.	Drain tray	K-12131000004317
29.	Fixed Speed Reciprocating Compressor	K-11101010012275
29.1	Starter	K-12031000001561
29.2	Protector	K-12031000001316
29.3	Electric appliance shield	K-12031000001171
30.	Compressor back cover	K-12931000000647
31.	Compressor mounting panel assembly	K-12231000005846
32.	Universal wheel (locking casters)	K-12931000000685
34.	Upper hinge assembly	K-12231000007166
106.	Spout plug	K-12631000000188
107.	Guard Rail Insert	KC MDK-501123456789